

STOP!

If you have any issues with product please contact our technical support team before returning it.

TECHNICAL SUPPORT

Technical Support : **1 (800) 881 9305**

1 (714) 666 1716 X2

Email : **support@ezq.com**

Service Hours : **Mon. - Fri. 08:00 AM - 05:00 PM P.S.T**

EZQuest®
Premium Digital Life Accessories

Quick Instruction Manual for
USB-C to HDMI 4K 60Hz Adapter with HDR
Part# X40016

You must have a computer that outputs HDR, as well as HDR monitor or TV in order to be able to see HDR.

Attention:

Please make sure that you select the correct port from your display INPUT so that your computer display can be shown.

Specification:

- Part Number: X40016
- UPC Code: 694307400160
- Connectors: USB-C™ (USB Type-C) to HDMI 4K 60Hz Female
- Supports: Up to 1080p at 60Hz or UHD (3840 by 2160) at 60Hz
- Length: 21.5cm/8.5 inches
- Power: USB-C/USB Type-C
- Thunderbolt 3 port compatible
- One (1) year warranty

How to connect to smart phones and tablets:

Note: Please make sure that your device has the same type of USB-C connectors. The best way is to compare your charging cable connector that comes with your device to make sure it is a USB-C connector.

Please follow steps below:



How to connect to computer:


Connect the USB-C connector to your computer USB-C port and the HDMI side of the Adapter to your HDMI cable that is connected to your monitor.



Please make sure that you select the correct HDMI from your projector, TV or your display INPUT so that your computer display can be shown.


Resolution Setting for Mac

Apple logo>System Preferences>Displays



Resolution Setting for Windows

Right click desktop > Display Settings



Graphics Setting for Mac

1. Mirror Display

Apple logo>System Preferences>Displays





Source device



HDMI Display
4K 30Hz

2. Extend Display

Apple logo>System Preferences >Displays





5

Graphic Settings for Windows

1. Clone Mode



Right click desktop >Graphics Settings >Display



6

2. Extended Display

Right click desktop >Graphics Settings >Display



7

How to Change the Resolution and Refresh Rate on Mac:

System Preferences, Click on Display, Under the Display:

While holding the Option button down, click on " Scale " twice then you can see the range of resolution
Then click on the " Show low resolution modes" box
Then you can choose the Refresh Rate available

Please email us with any questions or feedback you might have about our products to support@ezq.com.

1 (800) 881 9305

8