

STOP!

If you have any issues with the product, please contact our technical support team before returning it.

TECHNICAL SUPPORT

Technical Support : 1 (800) 881 9305

1 (714) 666 1716 X2

Email : support@ezq.com

Service Hours : Mon. - Fri. 08:00 AM - 05:00 PM P.S.T

EZQuest®
Premium Digital Life Accessories

Quick Instruction Manual for
Magnetic USB-C M.2 NVMe SSD Enclosure
Part# E12230

Package Contents:

- 1 x M.2 NVMe magnetic Enclosure (SSD not included)
- 1 x Rubber stopper
- 1 x Thermal Pad
- 1 x Data Cable
- 1 x User Manual



Product Introduction:

M.2 NVMe protocol, support for SSD specification 2230. Uplink interface USB-C, support 10Gbps high-speed transmission. Aluminium alloy housing with wave pattern to increase heat dissipation.


Tool-less installation, top cover Ball Spring locking with convenient click and stick. Small and lightweight, easy to carry.

Installation:

Step 1: Align the top cover opening and lift it off.



Step 2: Connect the 2230 (B+M Key/ M Key) SSD and insert a retaining rubber plug to secure the SSD.



Step 3: Put the top cover and snap it in.



Step 4: How to format your SSD so it can be used with your iPhone 15: You need to use APFS or HFS+ for the ProApps. ExFAT will work OK but it's probably better to format it to APFS which can be done in Disk Utility in about a minute.

Step 5: When you connect the EZQuest SSD to your iPhone and open the Video, you can see the USB-C word appear at the bottom, as well as ProRes HDR on top left side. In order to start recording ProRes HDR you must tap on ProRes HDR to activate it.



Step 6: After you are done shooting your video, you can unplug and connect the SSD to your computer to view the video.

Disk removal if connected to Mac computer:

1. After using the disk, click on the icon of the USB drive and move it to trash. If you do not eject the disk and force it to be removed, it can easily cause file loss and disk damage.

Disk removal if connected to Windows computer:

1. After using the disk, click on the icon of a USB drive in the bottom right corner of your computer and select "Eject EZQuestE12230 USB Drive", the names of different disks vary. If you do not eject the disk and force it to be removed, it can easily cause file loss and disk damage.

Cautions:

- Please avoid use in high temperature, low temperature, wet, dusty and long-term exposure to sunlight.
- Do not place the product in an environment with corrosive substances, and do not use other chemical solutions to clean the product.
- Keep the product out of reach of children and do not allow children to use the product unsupervised.
- Do not disassemble or repair the products and accessories without authorization.
- Gently clean the product with a dry cloth.

Specification:

- **Part Number:** E12230
- **UPC Code:** 694307122307
- **Input:** USB-C / USB Type-C
- **Adapting SSD:** 2230
- **Material:** Aluminum
- **Capacity:** Maximum 2TB
- **Supported Protocols:** NVMe: M Key / B&M Key
- **Uplink Interface:** 1x USB-C 3.1(10Gbps)
- **Compatible Systems:** Windows 11,10,8.1 and 7, Linux, Mac OS 10.2 and above
- **Dimension:**
61.8 x 61.8 x 13mm - 2.43 x 2.43 x 0.51 inches
- **Weight:** 3 Ounces
- One (1) year limited warranty

Please email us with any questions or feedback you might have about our products to support@ezq.com.

1 (800) 881 9305